



A dia = 10 Drill full dia x 1mm deep to clear self taper dimples in frame bracket

B dia = 5 & Tap M6. CSK to make screw heads flush.

Ac dia = 6 Drill this 'A' hole through to clear screw

Ad dia = 3.2 & Tap M4

Break all edges

Material = 10mm Aluminium plate

Use M6 x 25 CSK c/w nuts & spring washers screws to mount voltage regulator

M4 x 16 c/w spring & flat washer x 3 required to fix plate to frame and get good chassis earth

Suits BMW R80ST
 Enuralast Voltage Regulator Mounting Plate
 Drawn 21-11-2011 in
wozzasshed@bigpond.com